

SCH 12" Axe Box - Shrade SCH 4.5" Fixed Blade Box

- 3CR13 STEEL BLADE, GLASS FIBER NYLON HANDLE
- Lightweight
- Lanyard hole
- Sheath included
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: Shrade SCH 4.5" Fixed Blade Box
- Manufacturer: Shrade
- Product no.: EU1001765
- Mfr. No.: 1124284
- Size: 4.5"
- Delivery weight: 0.01kg
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Shrade SCH 4.5" Fixed Blade Knife](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH 12" Axe och Shrade SCH 4.5" Fixed Blade](#)

Safety Instruction Guide for Shrade SCH 4.5" Fixed Blade Knife

Introduction

Thank you for choosing the Shrade SCH 4.5" Fixed Blade Knife. This guide provides important safety instructions to ensure the safe use of your knife. Please read this guide carefully before using the product.

General Safety Guidelines

- Always handle the knife with care.
- Keep the knife out of reach of children.
- Use the knife only for its intended purpose.
- Inspect the knife for damage before each use.
- Store the knife in its sheath when not in use.
- Report any unsafe conditions or accidents to the relevant authorities.

Specific Safety Precautions for Use

- **Cutting Surface:** Always use a stable, flat cutting surface when using the knife to prevent slips.
- **Direction of Cut:** Cut away from your body and keep hands and fingers clear of the cutting path.
- **Grip:** Ensure a firm grip on the handle while using the knife to prevent accidents.
- **Lanyard Hole:** Use the lanyard hole to secure the knife when working in environments where it may be dropped.
- **Sheath:** Always use the sheath provided to protect the blade and prevent accidental cuts when not in use.

Instructions for Installation and Usage

1. **Unboxing:** Carefully remove the knife from the packaging. Dispose of packaging materials responsibly.
2. **Inspection:** Check the blade and handle for any signs of damage. Do not use if damaged.
3. **Usage:**
 - Hold the knife by the handle with a firm grip.
 - Position the blade at the desired angle for cutting.
 - Apply even pressure while cutting, avoiding excessive force.
4. **Cleaning:** After use, clean the blade with a damp cloth and dry thoroughly to prevent rust.
5. **Storage:** Store the knife in a dry place, in its sheath, to protect the blade and ensure safety.

Disposal Instructions

- Dispose of the knife responsibly. If it is no longer usable, consider recycling parts where possible.
- Always ensure the blade is secured in the sheath before disposal to prevent accidents.

Contact Information for Further Support

For any safety inquiries or concerns regarding your Shrade SCH 4.5" Fixed Blade Knife, please refer to the manufacturer's website or customer service for assistance.

By following these guidelines, you can ensure a safe and enjoyable experience with your Shrade SCH 4.5" Fixed Blade Knife. Thank you for choosing Shrade, and stay safe!

Säkerhetsinstruktioner för Shrade SCH 12" Axe och Shrade SCH 4.5" Fixed Blade

Introduktion

Tack för att du valt Shrade SCH 12" Axe och Shrade SCH 4.5" Fixed Blade. Denna produkt är designad för att ge hög prestanda och hållbarhet. För att säkerställa en säker och effektiv användning av produkten, vänligen följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens instruktioner.
- Förvara produkten utom räckhåll för barn och otillbörlig användning.
- Kontrollera produkten för skador innan användning. Använd inte om produkten är skadad.
- Rapportera alla osäkra produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser av produkter via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder vid användning

- Använd alltid skyddsutrustning som handskar och skyddsglasögon när du använder produkten.
- Använd produkten endast för avsedd användning. Använd inte för andra ändamål.
- Håll alltid ett fast grepp om handtaget och använd produkten med båda händerna.
- Undvik att använda produkten i fuktiga eller hala miljöer.
- Använd inte produkten när du är trött eller under påverkan av alkohol eller droger.

Instruktioner för installation och användning

1. **Förberedelse:** Kontrollera att arbetsområdet är rent och fritt från hinder.
2. **Användning av Axe:**
 - Håll axeln med båda händerna, med ena handen på handtaget och den andra handen längre ner för stabilitet.
 - Sikta noggrant innan du slår och se till att inget befinner sig i vägen för axeln.
3. **Användning av Fixed Blade:**
 - Ta bort kniven från fodralet med försiktighet.
 - Använd kniven på en stabil yta och undvik att rikta den mot dig själv eller andra.
4. **Avsluta användning:** Efter användning, rengör produkten och förvara den på en säker plats.

Avfallsinstruktioner

- Kassera eventuella trasiga eller oanvändbara delar av produkten på ett miljövänligt sätt.
- Följ lokala riktlinjer för avfallshantering för metall och plast.

Kontaktinformation för ytterligare support

För frågor eller säkerhetsrelaterade ärenden, vänligen kontakta din lokala återförsäljare eller besök tillverkarens webbplats för mer information. Det är viktigt att ha en EUbaserad kontakt för att hantera säkerhetsfrågor.

Genom att följa dessa riktlinjer och instruktioner kan du säkerställa en säker och effektiv användning av Shrade SCH 12" Axe och Shrade SCH 4.5" Fixed Blade. Tack för att du prioriterar säkerhet.