

SCH 12" Axe Box - SCH 4.5" Fixed Blade Clam

- 3CR13 STEEL BLADE, GLASS FIBER NYLON HANDLE
- Lightweight
- Lanyard hole
- Sheath included
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: SCH 4.5" Fixed Blade Clam
- Manufacturer: Shrade
- Product no.: EU1001766
- Mfr. No.: 1124285
- Size: 4.5"
- Delivery weight: 0.01kg
- UPC: 661120081623

Table of Contents

- [Startpage](#)
- [English: Shrade SCH 12" Axe Box SCH 4.5" Fixed Blade Clam Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH 12" Axe Box och SCH 4.5" Fixed Blade](#)

Shrade SCH 12" Axe Box SCH 4.5" Fixed Blade Clam Safety Instructions

Introduction

Thank you for choosing the Shrade SCH 12" Axe Box with the SCH 4.5" Fixed Blade. This guide provides essential safety instructions to ensure safe use and maintenance of your axe. Please read this manual carefully before using the product to maximize safety and performance.

General Safety Guidelines

- Always use the axe for its intended purpose.
- Keep the axe out of reach of children and vulnerable individuals.
- Inspect the axe before each use for any signs of damage or wear.
- Store the axe in its sheath when not in use to prevent accidental injury.
- Do not use the axe if you are under the influence of drugs or alcohol.
- Wear appropriate personal protective equipment (PPE) such as gloves and safety glasses when using the axe.

Specific Safety Precautions for Use

- Ensure you have a stable footing and a clear workspace free of obstacles.
- Always cut away from your body and keep your hands clear of the cutting path.
- Use the axe only when you are in a safe position and can maintain control.
- Avoid using the axe in wet or slippery conditions.
- Do not attempt to catch the axe if it slips from your grip.
- Be aware of your surroundings, including other people and animals, when using the axe.

Instructions for Installation and Usage

• Usage Instructions:

- Hold the axe firmly by the handle, ensuring a secure grip.
- Position the axe at a comfortable angle for cutting.
- Swing the axe with controlled force to achieve the desired cut.
- After use, clean the blade with a dry cloth and store it in the sheath.

• Installation Instructions:

- Remove the axe from its packaging carefully.
- Inspect the axe for any defects or damage.
- If applicable, attach any accessories according to the manufacturer's instructions.
- Ensure the sheath is in good condition before storing the axe.

Disposal Instructions

- Dispose of the axe responsibly in accordance with local regulations.
- If the axe is damaged beyond repair, ensure the blade is safely covered before disposal to prevent injury.
- Recycle materials where possible, following local recycling guidelines.

Contact Information for Further Support

For any questions or concerns regarding the safety and use of your Shrade SCH 12" Axe Box SCH 4.5" Fixed Blade, please refer to the manufacturer's contact information provided on the packaging or visit the manufacturer's website for more details.

Conclusion

By following these safety instructions, you can ensure a safe and effective experience with your Shrade SCH 12" Axe Box SCH 4.5" Fixed Blade. Always prioritize safety and stay informed about best practices for using your axe. Thank you for your attention to these important guidelines.

Säkerhetsinstruktioner för Shrade SCH 12" Axe Box och SCH 4.5" Fixed Blade

Introduktion

Tack för att du valt Shrade SCH 12" Axe Box och SCH 4.5" Fixed Blade. Dessa verktyg är designade för att ge hög prestanda och hållbarhet. För att säkerställa säker användning och lång livslängd, vänligen följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera produkten regelbundet för skador eller slitage.
- Rapportera eventuella farliga produkter eller olyckor till myndigheterna.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar och ögonskydd när du använder axeln eller kniven.
- Se till att arbetsområdet är rent och fritt från hinder.
- Använd aldrig produkten under påverkan av alkohol eller droger.
- Håll alltid bladet borta från kroppen och andra personer när du arbetar.
- Förvara produkten på en säker plats när den inte används.

Instruktioner för installation och användning

- För axeln:
 - Kontrollera att axelbladet är ordentligt fäst innan användning.
 - Använd axeln på ett stabilt underlag och rikta alltid bladet bort från kroppen.
 - Vid behov, använd ett skyddande fodral när axeln inte är i bruk.
- För den fasta kniven:
 - Ta bort kniven från fodralet försiktigt för att undvika skador.
 - Använd kniven för avsett ändamål och undvik att använda den för andra syften.
 - Efter användning, rengör kniven noggrant och återför den till fodralet.

Avfallshanteringsinstruktioner

- Kasta inte produkten i hushållsavfall.
- Följ lokala riktlinjer för avfallshantering och återvinning av metall och plast.
- Om produkten är skadad eller inte längre användbar, se till att den hanteras på ett säkert sätt för att förhindra skador.

Kontaktinformation för ytterligare support

För frågor eller mer information om produkten, vänligen kontakta en lokal återförsäljare eller besök tillverkarens webbplats för support.