

SCH 12" Axe Box - SCH 4" Fixed Blade Drop Point Clam

- 9CR18MOV STEEL BLADE, INJECTION PP & TPR HANDLE
- Lightweight
- Lanyard hole
- Sheath included
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: SCH 4" Fixed Blade Drop Point Clam
- Manufacturer: Shrade
- Product no.: EU1001768
- Mfr. No.: 1124287
- Size: 4
- Delivery weight: 0.01kg
- UPC: 661120081647

Table of Contents

- [Startpage](#)
- [English: Shrade SCH 12" Axe and SCH 4" Fixed Blade Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH 12" Axe Box och SCH 4" Fixed Blade Drop Point](#)

Shrade SCH 12" Axe and SCH 4" Fixed Blade Safety Instructions

Introduction

Thank you for choosing the Shrade SCH 12" Axe and SCH 4" Fixed Blade Drop Point. This guide provides essential safety instructions to ensure the safe use and maintenance of your products. Please read this guide carefully before using the axe and knife to minimize the risk of injury.

General Safety Guidelines

- Always use the axe and knife for their intended purposes.
- Keep the products out of reach of children and vulnerable individuals.
- Inspect the axe and knife before each use for any signs of damage or wear.
- Do not use the axe or knife if they are damaged or if the blade is dull.
- Store the axe and knife in a safe place, preferably in their sheaths when not in use.
- Use protective gear, such as gloves and safety glasses, when using the axe and knife.
- Be aware of your surroundings and ensure that no one is in the vicinity when using the axe or knife.
- Do not engage in horseplay or distractions while using these tools.

Specific Safety Precautions for Use

Axe Safety Precautions

- Always cut away from your body and keep your hands clear of the cutting path.
- Use the axe on a stable surface to prevent slips or accidents.
- Do not use the axe for prying or as a hammer.
- Ensure that the axe is securely held with both hands during use.
- When chopping, maintain a firm footing and a balanced stance.

Knife Safety Precautions

- Always cut away from your body and keep your fingers clear of the cutting path.
- Do not attempt to catch a falling knife.
- Use a cutting board or a stable surface when using the knife.
- Avoid using the knife for tasks it is not designed for, such as opening cans or prying.
- Keep the knife blade sharp for safe and effective use.

Instructions for Installation and Usage

Axe Usage Instructions

1. **Hold the Axe Properly:** Grip the handle firmly with both hands. Your dominant hand should be near the axe head, while your other hand should be at the end of the handle.
2. **Choose a Suitable Cutting Area:** Find a stable and flat surface for chopping. Ensure that there are no obstacles nearby.
3. **Position the Wood:** Place the wood securely on the cutting surface.
4. **Chop with Care:** Swing the axe down toward the wood, ensuring your hands are clear of the cutting path.
5. **Store Safely:** After use, clean the axe and store it in its sheath.

Knife Usage Instructions

1. **Hold the Knife Correctly:** Grip the handle firmly with your dominant hand. Ensure that your fingers are

positioned away from the blade.

2. **Prepare the Cutting Surface:** Use a stable cutting board to prevent slipping.
3. **Cut with Caution:** Use smooth, controlled motions to cut. Always cut away from your body.
4. **Clean After Use:** Wash the knife with soap and water, and dry it thoroughly before storing.
5. **Store Safely:** Place the knife back in its sheath when not in use.

Disposal Instructions

When disposing of the axe and knife, follow these guidelines: * Ensure that the products are no longer usable before disposal. * Wrap the blade securely to prevent injury during disposal. * Dispose of the axe and knife in accordance with local regulations for metal waste. * Do not dispose of the products in regular household waste.

Contact Information for Further Support

For any safety inquiries or further support regarding the Shrade SCH 12" Axe and SCH 4" Fixed Blade, please refer to the contact information provided on the product packaging or visit the manufacturer's website.

By following these safety instructions, you can ensure a safe and enjoyable experience with your Shrade products. Always prioritize safety and be mindful of your surroundings while using these tools. Thank you for your attention to these important guidelines.

Säkerhetsinstruktioner för Shrade SCH 12" Axe Box och SCH 4" Fixed Blade Drop Point

Introduktion

Tack för att du valt Shrade SCH 12" Axe Box och SCH 4" Fixed Blade Drop Point. Denna produkt är designad för att ge säker och effektiv användning. Vänligen läs igenom dessa säkerhetsinstruktioner noggrant för att säkerställa en trygg användning.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens instruktioner.
- Håll produkten utom räckhåll för barn och andra sårbara grupper.
- Kontrollera produkten regelbundet för skador eller slitage innan användning.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar och skyddsglasögon när du använder produkten.
- Skär alltid bort från kroppen för att minimera risken för skador.
- Förvara produkten i det medföljande fodralet när den inte används.
- Var försiktig med produkten när den är blöt eller i hala förhållanden.
- Använd inte produkten om den har skador eller om bladet är slitet.

Instruktioner för installation och användning

- Kontrollera att produkten är i gott skick innan användning.
- Håll handtaget rent och torrt för att förhindra glidning.
- För att använda axen, håll den med båda händerna och svinga den med kontroll.
- För den fasta bladkniven, använd det medföljande fodralet för säker förvaring och transport.
- Rengör produkten efter användning med en fuktig trasa och torka noggrant.

Avfallsinstruktioner

- Kasta inte produkten i hushållssoporna.
- Följ lokala riktlinjer för avfallshantering och återvinning av metallprodukter.
- Se till att produkten är oanvändbar innan du slänger den för att förhindra olyckor.

Kontaktinformation för ytterligare support

För frågor eller mer information om produktsäkerhet, vänligen kontakta en lokal återförsäljare eller besök tillverkarens officiella webbplats.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet.