

4.25" Fixed Blade Box

- 3CR13 STEEL BLADE, GLASS FIBER NYLON HANDLE
- Lightweight
- Lanyard hole
- Hard polymer sheath included
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: 4.25" Fixed Blade Box
- Manufacturer: Shrade
- Product no.: EU1001769
- Mfr. No.: 1124288
- Size: 4.25
- Delivery weight: 0.01kg
- UPC: 661120081654

Table of Contents

- [Startpage](#)
- [English: Shrade 4.25" Fixed Blade Box Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade 4.25" Fixed Blade Box](#)

Shrade 4.25" Fixed Blade Box Safety Instructions

Introduction

Thank you for choosing the Shrade 4.25" Fixed Blade Box. This guide provides important safety instructions to ensure the safe use of your knife. Please read this manual carefully before using the product to understand its features and safety precautions.

General Safety Guidelines

- Always handle the knife with care to avoid accidents.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use to ensure it is in good condition.
- Do not use the knife for purposes other than intended.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure the knife is stored in its hard polymer sheath when not in use to prevent accidental cuts.
- Use the knife on a stable surface to maintain control during cutting tasks.
- Always cut away from your body and keep your hands clear of the cutting path.
- Avoid using excessive force while cutting; let the blade do the work.
- If the knife becomes dull, do not attempt to sharpen it unless you are trained to do so.
- Do not attempt to modify the knife in any way.
- Be cautious when using the knife in wet or slippery conditions.

Instructions for Installation and Usage

1. **Unboxing:** Carefully remove the knife from its packaging. Ensure you do not cut yourself during this process.
2. **Initial Inspection:** Check the blade and handle for any defects. If you notice any issues, do not use the knife and report it.
3. **Using the Knife:**
 - Hold the knife firmly by the handle.
 - Position the item you are cutting securely on a stable surface.
 - Begin cutting with a controlled motion, ensuring you are aware of your hand positions.
4. **Storage:** After use, clean the knife with a dry cloth and place it back into the hard polymer sheath. Store the knife in a safe location away from children.
5. **Maintenance:** Regularly inspect the knife for wear and tear, and replace it if necessary.

Disposal Instructions

- When the knife reaches the end of its life or is no longer safe to use, dispose of it responsibly.
- Wrap the blade in protective material to prevent injury during disposal.
- Check local regulations for proper disposal methods of sharp objects.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the manufacturer's website or contact your retailer. Ensure you have your product details ready for a more efficient response.

Thank you for your attention to these safety instructions. Your safety is our priority. Enjoy using your Shrade 4.25" Fixed Blade Box responsibly!

Säkerhetsinstruktioner för Shrade 4.25" Fixed Blade Box

Introduktion

Tack för att du valt Shrade 4.25" Fixed Blade Box. Denna guide ger viktiga säkerhetsinstruktioner för att säkerställa en säker användning av produkten. Läs igenom dessa instruktioner noggrant innan du använder kniven.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Inspektera produkten regelbundet för skador eller slitage.
- Rapportera eventuella defekter eller farliga situationer till relevanta myndigheter.
- Kontrollera regelbundet EU:s Safety Gateplattform för återkallelseuppdateringar.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar när du hanterar kniven för att undvika skador.
- Håll kniven i ett säkert grepp och undvik att använda den i hala eller osäkra miljöer.
- Använd kniven endast för dess avsedda syfte; undvik att använda den för att öppna paket eller skära material som inte är avsett för knivanvändning.
- Förvara kniven i det medföljande hölstret när den inte används för att förhindra oavsiktliga skador.
- Undvik att använda kniven under påverkan av alkohol eller droger.

Instruktioner för installation och användning

- Ta bort kniven från hölstret genom att dra den rakt ut, håll kniven i ett säkert grepp.
- Använd kniven på en stabil yta för att minimera risken för olyckor.
- När du är klar med att använda kniven, rengör den noggrant och torka den för att förhindra rost och skador.
- För att förvara kniven, sätt tillbaka den i det hårda polymerhølstret och placera den på en säker plats.

Avfallshanteringsinstruktioner

- Kasta inte kniven i vanligt avfall. Följ lokala riktlinjer för avfallshantering.
- Om kniven är skadad eller inte längre användbar, överväg att lämna den till en återvinningsstation som hanterar metallavfall.

Kontaktinformation för ytterligare stöd

För frågor eller rapporter om säkerhetsproblem, vänligen kontakta en lokal återförsäljare eller besök tillverkarens officiella webbplats.

Tack för att du följer dessa säkerhetsinstruktioner och använder Shrade 4.25" Fixed Blade Box på ett ansvarsfullt och säkert sätt.