

3.25" Ultraglide Folder Box - Shrade 3.25" Ultraglide Folder Clam

- 9CR18MOV STEEL BLADE, GLASS FIBER NYLON HANDLE
- Liner lock
- Dual thumb studs
- Lanyard hole
- Stonewash finish blade

NO IMAGE
AVAILABLE

Attributes

- Name: Shrade 3.25" Ultraglide Folder Clam
- Manufacturer: Shrade
- Product no.: EU1001772
- Mfr. No.: 1124291
- Size: 3.25"
- Delivery weight: 0.01kg
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Shrade 3.25" Ultraglide Folder Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade 3.25" Ultraglide Folder](#)

Shrade 3.25" Ultraglide Folder Safety Instructions

Introduction

Thank you for purchasing the Shrade 3.25" Ultraglide Folder. This safety instruction guide is designed to ensure your safe use of the product while complying with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before using the knife.

General Safety Guidelines

- Ensure safe handling and use of the knife at all times.
- Keep the knife out of reach of children and vulnerable individuals.
- Always inspect the knife for damage before use. Do not use if any part is broken or malfunctioning.
- Use the knife only for its intended purpose. Misuse may lead to injury.
- Always cut away from your body and keep your fingers clear of the blade.
- Store the knife in a secure place when not in use to prevent accidents.
- Be aware of your surroundings while using the knife to avoid accidents with other people or objects.

Specific Safety Precautions for Use

- **Blade Safety:** The blade is made of 9CR18MOV steel and is sharp. Handle it with care.
- **Liner Lock:** Ensure the liner lock is fully engaged when the knife is open. This prevents accidental closure during use.
- **Dual Thumb Studs:** Use the dual thumb studs to open the knife safely. Do not force the blade open.
- **Lanyard Hole:** If using a lanyard, ensure it is securely attached to avoid loss of the knife.
- **Stonewash Finish:** The stonewash finish may affect grip under wet conditions. Exercise caution when using the knife in such conditions.

Instructions for Installation and Usage

1. Opening the Knife:

- Hold the knife firmly in one hand.
- Use your thumb to press on one of the dual thumb studs to open the blade.
- Ensure the liner lock clicks into place, confirming the blade is securely open.

2. Using the Knife:

- Hold the handle firmly with your dominant hand.
- Use your other hand to stabilize the material you are cutting.
- Cut away from your body and keep your fingers clear of the blade.

3. Closing the Knife:

- Ensure that your fingers are clear of the blade.
- Press the liner lock to release the blade.
- Carefully fold the blade back into the handle until it clicks into place.

4. Cleaning and Maintenance:

- Clean the blade with a soft cloth after use to prevent rust and maintain sharpness.
- Store the knife in a dry place when not in use.

Disposal Instructions

- Dispose of the knife responsibly at a designated waste facility.
- If the knife is broken or damaged, ensure it is securely wrapped to prevent injury during disposal.
- Follow local regulations regarding the disposal of sharp objects.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Shrade 3.25" Ultraglide Folder, please refer to the contact information provided on the packaging or the manufacturer's website.

Conclusion

By following these safety instructions, you can ensure safe and effective use of your Shrade 3.25" Ultraglide Folder. Always prioritize safety and responsible handling to prevent accidents. Thank you for choosing Shrade.

Säkerhetsinstruktioner för Shrade 3.25" Ultraglide Folder

Introduktion

Tack för att du valt Shrade 3.25" Ultraglide Folder. Denna produkt är designad för att ge användaren en säker och effektiv upplevelse. För att säkerställa korrekt användning och undvika eventuella risker, vänligen läs noggrant igenom dessa säkerhetsinstruktioner.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera alltid kniven för skador innan användning.
- Använd kniven endast för avsett ändamål.
- Följ lokala lagar och förordningar angående knivanvändning.

Specifika säkerhetsåtgärder för användning

- **Skärbladets säkerhet:**
 - Var försiktig när du öppnar och stänger kniven för att undvika skador.
 - Använd alltid kniven bort från kroppen och andra personer.
- **Låsning:**
 - Kontrollera att liner lock är korrekt låst innan användning.
- **Hantering:**
 - Använd alltid ett fast grepp om handtaget för att förhindra halka.
- **Användning av tummestud:**
 - Använd tummestud endast för att öppna kniven; undvik att trycka på den under användning.
- **Snoddhål:**
 - Använd snoddhålet för att fästa kniven på en säker plats när den inte används.

Instruktioner för installation och användning

1. **Öppna kniven:**
 - Tryck på tummestud för att öppna bladet.
 - Kontrollera att liner lock är i låst läge.
2. **Använd kniven:**
 - Använd endast för skärande uppgifter.
 - Håll kniven i en vinkel som är säker för dig och omgivningen.
3. **Stäng kniven:**
 - Tryck på liner lock för att frigöra bladet.
 - Stäng bladet försiktigt tills det klickar på plats.

Avfallshantering

- Kassera kniven på ett ansvarsfullt sätt.
- Om kniven är skadad eller trasig, se till att den inte kan användas av andra.
- Följ lokala riktlinjer för avfallshantering av metallprodukter.

Kontaktinformation för vidare support

För frågor eller rapportering av osäkra produkter, vänligen kontakta en lokal myndighet eller besök EU:s Safety Gateplattform för att få mer information om återkallelser och säkerhetsåtgärder.

Avslutande anmärkningar

Detta dokument är utformat för att säkerställa din säkerhet och välbefinnande vid användning av Shrade 3.25" Ultraglide Folder. Genom att följa dessa instruktioner bidrar du till en säker och positiv användarupplevelse. Tack för att du valt vår produkt!