

Shovel/Saw Combo Box

- 3CR13 STEEL BLADE, ALUMINUM HANDLE
- Lightweight
- Lanyard hole
- Sheath included
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: Shovel/Saw Combo Box
- Manufacturer: Shrade
- Product no.: EU1001773
- Mfr. No.: 1124292
- Delivery weight: 0.01kg
- UPC: 661120081692

Table of Contents

- [Startpage](#)
- [English: Shrade Shovel/Saw Combo Box Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade Shovel/Saw Combo Box](#)

Shrade Shovel/Saw Combo Box Safety Instructions

Introduction

Thank you for choosing the Shrade Shovel/Saw Combo Box. This product combines a durable shovel and saw, designed for outdoor use. To ensure your safety and the longevity of the product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always use the product as intended. Misuse can lead to injury.
- Keep the shovel/saw combo out of reach of children and pets when not in use.
- Inspect the product before each use for any signs of damage or wear.
- Store the product in a dry place to prevent rust and deterioration.
- Always wear appropriate safety gear, such as gloves and protective eyewear, when using the shovel/saw.

Specific Safety Precautions for Use

- **Blade Safety:**
 - The blade is sharp. Handle with care to avoid cuts.
 - Do not attempt to touch or clean the blade while it is in use.
- **Lanyard Hole:**
 - Use the lanyard hole to secure the shovel/saw when not in use, preventing accidental drops.
- **Sheath:**
 - Always use the sheath provided when storing the blade to protect yourself and others from accidental contact.
- **Weight Consideration:**
 - The product is lightweight, but be cautious of overexertion when using it for extended periods.

Instructions for Installation and Usage

1. **Preparation:**
 - Ensure you are in a safe and suitable environment for using the shovel/saw.
 - Clear the area of any obstacles or hazards.
2. **Using the Shovel:**
 - Hold the shovel firmly by the aluminum handle.
 - Use a stable stance and apply downward force to dig or move materials.
3. **Using the Saw:**
 - Ensure the blade is securely locked in place before use.
 - Position the saw at the desired angle and apply even pressure to cut through materials.
4. **After Use:**
 - Clean the blade and handle with a dry cloth to remove dirt and moisture.
 - Store the shovel/saw in its sheath in a dry, safe location.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- If the product is damaged beyond repair, ensure that it is disposed of in a way that prevents harm to others, especially children and pets.

Contact Information for Further Support

For any safety inquiries or further assistance, please contact your local retailer or visit the manufacturer's website for support resources.

Säkerhetsinstruktioner för Shrade Shovel/Saw Combo Box

Introduktion

Tack för att du valt Shrade Shovel/Saw Combo Box. Denna produkt är utformad för att vara både funktionell och säker. För att säkerställa en trygg användning, vänligen läs dessa säkerhetsinstruktioner noggrant innan du använder produkten.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Kontrollera produkten för skador innan användning. Använd inte om den är skadad.
- Förvara produkten utom räckhåll för barn och andra sårbara grupper.
- Rapportera eventuella farliga produkter eller olyckor till myndigheterna.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar när du hanterar kniven eller sågen.
- Se till att området där du arbetar är fritt från hinder och personer.
- Använd inte produkten för andra ändamål än vad den är avsedd för.
- Var särskilt försiktig när du arbetar med hårda eller tunga material.
- Håll bladet rent och fritt från skräp för att förhindra skador.

Instruktioner för installation och användning

- Kontrollera att alla delar är inkluderade i förpackningen innan installation.
- Fäll ut shovel/saw kombinationen genom att dra i handtaget tills det klickar på plats.
- För att använda sågen, se till att den är ordentligt låst innan du börjar såga.
- Använd en jämn och kontrollerad rörelse när du sågar för att undvika olyckor.
- För att stänga produkten, tryck på låsknappen och fäll ihop handtaget.

Avfallshanteringsanvisningar

- Avlägsna alla batterier (om tillämpligt) innan du kasserar produkten.
- Kasta produkten enligt lokala föreskrifter för avfallshantering.
- Återvinn material om möjligt, såsom aluminium och stål.

Kontaktinformation för vidare stöd

För frågor eller mer information om säkerheten kring denna produkt, vänligen kontakta den lokala distributören eller återförsäljaren. Det finns även en EUbaserad kontaktpunkt för säkerhetsfrågor.

Tack för att du följer dessa säkerhetsinstruktioner. Vi hoppas att du får stor nytta av din Shrade Shovel/Saw Combo Box!