

PROTEUS™ Ulu Knife

The ULU knife is all-purpose—dating all the way back to 2500 B.C. Bubba has taken this well-known design out of the stone age; incorporating the latest in steel and polymer technologies. Proteus™ is our versatile kitchen tool, great for cleaning fish, cutting meats, vegetables, cheeses and even pizza. This unique design creates efficient ergonomics and a rocking motion that results in less wrist and grip fatigue for effortless cuts.

NO IMAGE
AVAILABLE

Attributes

- Name: PROTEUS™ Ulu Knife
- Manufacturer: BUBBA
- Product no.: EU1001780
- Mfr. No.: 1989606
- Delivery weight: 0.01kg
- UPC: 661120079842

Table of Contents

- [Startpage](#)
- [English: BUBBA PROTEUS™ Ulu Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA PROTEUS™ Ulu Knife](#)

BUBBA PROTEUS™ Ulu Knife Safety Instructions

Introduction

Thank you for choosing the BUBBA PROTEUS™ Ulu Knife. This allpurpose knife is designed for a variety of culinary tasks, from cleaning fish to slicing meats and vegetables. To ensure your safety and maximize the performance of your knife, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always handle the knife with care and keep it out of reach of children.
- Ensure the knife is stored in its sheath when not in use to prevent accidental cuts.
- Regularly inspect the knife for any damage or wear. Do not use a damaged knife.
- Keep the knife clean and dry to maintain its performance and prevent rust.
- Use the knife only for its intended purpose. Avoid using it for tasks that could cause injury or damage.
- If you experience any discomfort while using the knife, stop using it immediately.

Specific Safety Precautions for Use

- Wear cutresistant gloves when handling the knife, especially during cleaning or preparation tasks.
- Always cut away from your body to minimize the risk of injury.
- Use a stable cutting surface to prevent slips and accidents.
- Avoid distractions while using the knife to maintain focus on the task at hand.
- Do not attempt to catch a falling knife. Let it fall to avoid injury.

Instructions for Installation and Usage

1. Unpacking the Knife

- Carefully remove the knife from its packaging.
- Inspect the knife for any visible damage before use.

2. Using the Knife

- Hold the knife by the handle with a firm grip. Ensure your fingers are away from the blade.
- For cutting, place the item on a stable surface. Use a cutting board for best results.
- Apply even pressure while cutting to ensure smooth and safe operation.

3. Cleaning and Maintenance

- After each use, wash the knife with warm, soapy water and dry it immediately.
- Avoid using abrasive cleaners or scouring pads as they may damage the blade.
- Periodically check the sharpness of the blade. Sharpen as needed using a suitable knife sharpener.

4. Storing the Knife

- Always store the knife in its easylocking sheath when not in use.
- Keep the knife in a dry place away from moisture to prevent rust.

Disposal Instructions

- When the knife reaches the end of its life, dispose of it responsibly.
- Wrap the knife in protective material (e.g., cardboard) to prevent injury during disposal.
- Check local regulations for proper disposal methods of kitchen knives.

Contact Information for Further Support

For safety inquiries or to report unsafe products, please reach out to the appropriate EU contact point. Ensure you have the product details at hand for efficient assistance.

By following these safety instructions, you can enjoy the full benefits of your BUBBA PROTEUS™ Ulu Knife while ensuring your safety and the safety of others. Thank you for your attention, and happy cooking!

Säkerhetsinstruktioner för BUBBA PROTEUS™ Ulu Knife

Introduktion

Tack för att du valt BUBBA PROTEUS™ Ulu Knife. Detta mångsidiga köksverktyg är designat för att ge en säker och effektiv användning. För att säkerställa en trygg och korrekt användning av produkten, vänligen läs igenom dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven enligt dess avsedda syfte för att förhindra skador.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Inspektera kniven innan användning för att säkerställa att den är i gott skick och fri från skador.
- Använd skyddshandskar vid hantering av kniven för att minimera risken för skador.
- Förvara kniven på en säker plats, helst i det medföljande fodralet, när den inte används.

Specifika säkerhetsåtgärder för användning

- Använd kniven på en stabil och plan yta för att undvika olyckor.
- Skär alltid bort från dig själv för att minimera risken för skador.
- Undvik att använda kniven på hårda ytor som kan skada bladet.
- Rengör kniven omedelbart efter användning för att förhindra bakterietillväxt och förlänga dess livslängd.
- Använd inte kniven om den är skadad eller sliten. Kontakta tillverkaren för råd.

Instruktioner för installation och användning

- Ta bort kniven från förpackningen och inspektera den för eventuella skador.
- För att använda kniven, håll det halkfria handtaget med ett fast grepp.
- Använd den böjda bladformen för att utföra snitt; detta ger en vaggande rörelse som minskar handledströtthet.
- Rengör kniven med varmt vatten och mild tvål efter varje användning. Torka den noggrant för att förhindra rost.
- Förvara kniven i det medföljande fodralet när den inte används för att skydda bladet och säkerställa säker förvaring.

Kassationsinstruktioner

- När kniven inte längre är i bruk eller är skadad, kassera den på ett säkert sätt.
- Kontrollera lokala riktlinjer för avfallshantering för att säkerställa korrekt kassering av metallprodukter.
- Om kniven är defekt, kontakta tillverkaren för information om återvinning eller kassering.

Kontaktinformation för vidare support

För frågor eller bekymmer angående säkerheten hos BUBBA PROTEUS™ Ulu Knife, vänligen kontakta tillverkaren för ytterligare information och support.

Tack för att du bidrar till en säker användning av våra produkter!