

Shears, Small - Shears, Medium

The Bubba Medium Shears are our most versatile shears within the Bubba shear family. The medium shears offer micro-serrated blades to cut monocarbon, fluorocarbon or braided line while also offering a hook eye cleaner, hook sharpener, descaler and a bottle opener. These shears can also be broken down for easy cleaning and/or used as a utility knife. Finally, our medium shears are equipped with our iconic, non-slip grip handles and titanium-nitride coated blades for ultimate protection against corrosion.

NO IMAGE
AVAILABLE

Attributes

- Name: Shears, Medium
- Manufacturer: BUBBA
- Product no.: EU1001796
- Mfr. No.: 1099914
- Delivery weight: 0.01kg
- UPC: 661120080008

Table of Contents

- [Startpage](#)
- [English: BUBBA Shears Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA Medium Shears](#)

BUBBA Shears Safety Instructions

Introduction

Thank you for choosing the BUBBA Medium Shears. These versatile shears are designed for durability and functionality, making them an essential tool for various outdoor activities. This guide provides important safety instructions to ensure the safe use of your shears, in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always use the shears as intended and follow the instructions provided in this guide.
- Keep the shears out of reach of children and vulnerable individuals.
- Inspect the shears before each use to ensure they are in good working condition.
- Do not use the shears for purposes other than those intended.
- Report any unsafe products or accidents to the appropriate authorities.
- Check the EU's Safety Gate platform for recall updates on this product.

Specific Safety Precautions for Use

- Handle the shears with care to avoid cuts or injuries.
- Use protective gloves if you are not accustomed to handling sharp tools.
- Ensure the shears are clean and free of debris before use.
- Do not attempt to modify or repair the shears yourself.
- Store the shears in a safe place when not in use, preferably in a protective sheath or case.
- Avoid using the shears in wet conditions if the grip becomes slippery.

Instructions for Installation and Usage

1. Initial Inspection:

- Check the shears for any visible damage or defects.
- Ensure that the blades are sharp and properly aligned.

2. Using the Shears:

- Hold the shears by the nonslip grip handle for optimal control.
- Use the microerrated blades to cut monocarbon, fluorocarbon, or braided line.
- Utilize the hook eye cleaner, hook sharpener, descaler, and bottle opener as needed.
- For cleaning, disassemble the shears according to the instructions provided in the maintenance section.

3. Cleaning and Maintenance:

- After each use, clean the shears with fresh water and mild soap to remove any residue.
- Dry the shears thoroughly to prevent corrosion.
- Regularly inspect the blades and handle for wear and tear.

4. Disassembly for Cleaning:

- Follow the manufacturer's instructions to safely detach the blades.
- Clean each component separately and reassemble once dry.

Disposal Instructions

- Dispose of the shears responsibly according to local regulations.
- If the shears are damaged beyond repair, ensure they are disposed of in a manner that prevents injury to others.
- Recycle any metal components if applicable.

Contact Information for Further Support

For any safety inquiries or further support regarding your BUBBA Medium Shears, please refer to the manufacturer's contact information provided with your product packaging.

Thank you for your attention to safety. Enjoy using your BUBBA Medium Shears responsibly!

Säkerhetsinstruktioner för BUBBA Medium Shears

Introduktion

Tack för att du valt BUBBA Medium Shears. Dessa saxar är utformade för att ge hög kvalitet och mångsidighet för dina behov. För att säkerställa en säker och effektiv användning av produkten, vänligen följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid saxarna på ett säkert sätt och undvik att skära i material som är för hårda eller farliga.
- Håll saxarna utom räckhåll för barn och andra sårbara grupper för att förhindra olyckor.
- Kontrollera saxarna regelbundet för skador eller slitage. Använd inte saxarna om de är skadade.
- Förvara saxarna på en säker plats när de inte används för att förhindra oavsiktlig skada.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd saxarna endast för avsedda ändamål. Skär inte i material som inte är avsedda för saxar.
- Var försiktig när du använder mikrotandade blad för att undvika att skada dig själv.
- Använd alltid grepphandtagen för att säkerställa maximalt grepp och kontroll, särskilt när saxarna är blöta.
- Vid rengöring, demontera saxarna försiktigt för att undvika skador.

Instruktioner för installation och användning

1. Användning:

- Håll saxarna i ett fast grepp vid handtagen.
- Använd den mikrotandade kanten för att skära genom monocarbon, fluorocarbon eller flätad lina.
- Använd krokögontvättaren och krokvässaren med försiktighet.
- Använd flasköppnaren endast för avsedda flaskor.

2. Rengöring:

- Demontera saxarna för att rengöra dem noggrant.
- Använd en mjuk trasa och mild tvål för att rengöra bladen.
- Torka av saxarna ordentligt efter rengöring för att förhindra rost.

3. Förvaring:

- Förvara saxarna på en torr och säker plats.
- Använd ett skyddande fodral om möjligt för att skydda bladen.

Avfallshanteringsinstruktioner

- När saxarna inte längre är användbara, kassera dem på ett miljövänligt sätt.
- Kontrollera lokala riktlinjer för avfallshantering för verktyg och metallprodukter.
- Undvik att kasta saxarna i allmänna sopor om möjligt.

Kontaktinformation för ytterligare support

För frågor eller mer information om säkerheten kring BUBBA Medium Shears, vänligen kontakta en lokal återförsäljare eller besök vår webbplats för mer information.

Tack för att du följer dessa säkerhetsinstruktioner. Vi önskar dig en säker och effektiv användning av dina BUBBA Medium Shears!