

Shears, Small - Shears, Large

The Bubba Large Shears are designed to withstand the harshest of conditions. The large shears come with micro-serrated blades to cut monocarbon, fluorocarbon or braided line, while also offering a carabineer to clip on for easy access. The included sheath can be clipped on your shorts or belt. These shears will also breakdown for easy cleaning. The large shears are equipped with our iconic, non-slip grip handles and titanium-nitride coated blades for ultimate protection against corrosion.

NO IMAGE
AVAILABLE

Attributes

- Name: Shears, Large
- Manufacturer: BUBBA
- Product no.: EU1001797
- Mfr. No.: 1099915
- Delivery weight: 0.01kg
- UPC: 661120080015

Table of Contents

- [Startpage](#)
- [English: BUBBA Shears Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA Shears](#)

BUBBA Shears Safety Instruction Guide

Introduction

Thank you for choosing the BUBBA Shears. These shears are designed for durability and efficiency in various conditions. To ensure your safety and the optimal performance of the product, please read and follow this safety instruction guide.

General Safety Guidelines

- Always use the shears as intended and according to the instructions provided.
- Keep the shears out of reach of children and vulnerable individuals to prevent accidents.
- Regularly inspect the shears for any signs of damage or wear. If damaged, discontinue use immediately.
- Ensure the shears are clean and free from debris before and after each use to maintain performance.
- Store the shears in a safe place, ideally in the included sheath, to prevent accidental cuts or injuries.

Specific Safety Precautions for Use

- **Cutting Surfaces:** Use the shears on stable surfaces to maintain control during cutting.
- **Grip:** Always hold the shears by the handles and ensure your grip is secure, especially when cutting wet materials.
- **Clipping and Sheathing:** When not in use, clip the shears securely in the sheath to avoid accidental exposure to the blades.
- **Cleaning:** Follow the cleaning instructions carefully to avoid damaging the blades or handles.
- **Avoiding Corrosion:** Rinse the shears with fresh water after exposure to saltwater and dry thoroughly to prevent corrosion.

Instructions for Installation and Usage

1. Unpacking:

- Carefully remove the shears from the packaging.
- Ensure all components, including the sheath and any additional tools, are present.

2. Usage:

- To use the shears, firmly grasp the nonslip grip handles.
- Position the material you wish to cut securely on a flat surface.
- Open the shears by separating the handles, then align the blades with the material.
- Squeeze the handles together to cut through the material, applying steady pressure.

3. Cleaning:

- After each use, rinse the shears under fresh water to remove any material residue.
- Wipe the blades and handles with a soft cloth to dry them completely.
- Store the shears in the sheath when not in use.

4. Maintenance:

- Check the microerrated blades regularly for wear and tear.
- If the blades become dull, seek professional sharpening services to maintain cutting efficiency.

Disposal Instructions

- Dispose of the shears responsibly in accordance with local regulations.
- If the shears are damaged beyond repair, ensure that they are disposed of in a way that prevents injury to others, such as wrapping them in a protective material before disposal.

Contact Information for Further Support

For any inquiries regarding safety or product issues, please refer to the manufacturer's contact details provided with the product packaging or on the official website.

By following these guidelines, you can enjoy the full benefits of your BUBBA Shears while ensuring your safety and the safety of others. Thank you for choosing BUBBA!

Säkerhetsinstruktioner för BUBBA Shears

Introduktion

Tack för att du valt BUBBA Shears. Dessa saxar är designade för att ge hög prestanda och säkerhet vid användning. Denna säkerhetsinstruktion är utformad för att hjälpa dig att använda produkten på ett säkert sätt och att informera om eventuella risker.

Allmänna säkerhetsriktlinjer

- Använd alltid saxarna enligt anvisningarna för att minimera risken för skador.
- Håll saxarna utom räckhåll för barn och sårbara grupper.
- Kontrollera saxarna regelbundet för skador eller slitage. Om du upptäcker några problem, avbryt användningen omedelbart.
- Använd saxarna endast för avsedda ändamål.
- Vid onlineköp, se till att köpa från auktoriserade återförsäljare för att säkerställa produktens äkthet och säkerhet.

Specifika säkerhetsåtgärder för användning

- Använd alltid saxarna med båda händerna för att säkerställa stabilitet och kontroll.
- Undvik att använda saxarna på hårda ytor som kan skada bladen.
- Se till att bladen är rena och fria från skräp innan användning.
- Var försiktig när du hanterar saxarna, särskilt när bladen är öppna.
- Använd skyddshandskar om du är känslig för skärskador eller om du arbetar i tuffa miljöer.

Instruktioner för installation och användning

1. Installation av fodral:

- Fäst fodralet på dina shorts eller bälte för enkel åtkomst.
- Kontrollera att fodralet sitter ordentligt fast innan du använder saxarna.

2. Användning av saxarna:

- Håll saxarna med ett fast grepp om de halkfria handtagen.
- För att klippa, placera linan mellan bladen och tryck ihop handtagen långsamt och jämnt.
- Använd SplitShot Crimp Tool för att säkra linor när det behövs.
- Efter användning, stäng saxarna och förvara dem i fodralet för att skydda bladen.

Avfallshanteringsinstruktioner

- När saxarna inte längre är användbara, se till att de kasseras på ett miljövänligt sätt.
- Separera metall och plastkomponenter för återvinning där det är möjligt.
- Kontakta lokala myndigheter för information om korrekt avfallshantering.

Kontaktinformation för ytterligare support

För frågor eller mer information om produktens säkerhet och användning, vänligen kontakta den angivna kontaktpunkten i EU.

Vi tackar för att du valt BUBBA Shears och önskar dig en säker och effektiv användning!