

Survival Ring Saw

We believe serious outdoorsmen demand superior performance within the gear they bring afield. Here at Hooyman, we engineer all out products knowing passionate hunters rely on technologically advanced tools to enhance their success in the woods. We do not settle for second best and refuse to sacrifice innovation for “standardized” necessity. That is precisely why we manufacture the best and most eclectic premium tree saws, handsaws, cutting and pruning accessories on the market.

NO IMAGE
AVAILABLE

Attributes

- Name: Survival Ring Saw
- Manufacturer: Hooyman
- Product no.: EU1001813
- Mfr. No.: 110104
- Delivery weight: 7kg
- UPC: 661120001140

Table of Contents

- [Startpage](#)
- [English: Hooyman Survival Ring Saw Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för Hooyman Survival Ring Saw](#)

Hooyman Survival Ring Saw Safety Instruction Guide

Introduction

Thank you for choosing the Hooyman Survival Ring Saw. This guide provides essential safety instructions to ensure the safe and effective use of your new tool. Please read this document carefully before using the product to minimize risks and enhance your outdoor experience.

General Safety Guidelines

- Always use the ring saw in a welllit area to ensure visibility.
- Keep the saw away from children and vulnerable individuals.
- Inspect the ring saw before each use for any signs of damage or wear.
- Store the saw in a safe location when not in use, out of reach of children.
- Follow all local laws and regulations regarding the use of cutting tools in outdoor settings.
- Report any unsafe products or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE), including gloves and safety glasses, to protect against cuts and flying debris.
- Use the saw only for its intended purpose: cutting wood, plastic, bone, and soft metals.
- Do not attempt to cut materials that exceed the specified limits of the saw.
- Maintain a firm grip on the saw while cutting to prevent slipping.
- Always cut away from your body and keep hands clear of the cutting path.
- Avoid using the saw in wet or slippery conditions to prevent accidents.

Instructions for Installation and Usage

1. Preparation

- Ensure you have a clear and safe workspace.
- Gather all necessary equipment, including the Hooyman Survival Ring Saw.

2. Using the Saw

- Hold the large rings firmly with both hands.
- Insert a stick or rod through the rings for added grip if needed.
- Position the saw at the desired cutting angle and apply steady pressure while pulling the saw back and forth.
- Use the saw to cut through materials with a maximum diameter of 4 inches.

3. PostUse Care

- Clean the saw after each use to remove any debris or sap.
- Store the saw in a dry place to prevent rust or corrosion.
- Regularly inspect the saw for any signs of wear or damage.

Disposal Instructions

- Dispose of the Hooyman Survival Ring Saw in accordance with local regulations for metal products.
- Do not dispose of the saw in regular household waste. Instead, consider recycling options available in

your area.

Contact Information for Further Support

- For any inquiries regarding the safety and use of the Hooyman Survival Ring Saw, please reach out to your local retailer or visit the manufacturer's website for additional resources.

By following these safety instructions, you can ensure a safer and more enjoyable experience with your Hooyman Survival Ring Saw. Thank you for prioritizing safety in your outdoor adventures!

Säkerhetsinstruktioner för Hooyman Survival Ring Saw

Introduktion

Tack för att du valt Hooyman Survival Ring Saw. Denna produkt är designad för att ge överlägsen prestanda och säkerhet för friluftsentusiaster. För att säkerställa en trygg och effektiv användning av din ringsåg, vänligen läs igenom och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt dessa instruktioner för att minimera riskerna för skador.
- Kontrollera alltid produkten innan användning för att säkerställa att den är i gott skick.
- Förvara produkten utom räckhåll för barn och sårbara grupper.
- Rapportera alla osäkra produkter och olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd skyddsglasögon för att skydda ögonen från spån och skräp.
- Använd handskar för att skydda händerna från skador.
- Se till att arbetsområdet är fritt från hinder och farliga material.
- Använd alltid sågen på en stabil yta.
- Håll ett fast grepp om sågen under användning för att förhindra att den glider.
- Använd inte sågen om du är trött eller om du tar mediciner som kan påverka din reaktionsförmåga.

Instruktioner för installation och användning

Installation

1. Kontrollera att alla delar är inkluderade och i gott skick.
2. Montera sågen enligt tillverkarens anvisningar.
3. Se till att alla fästen är ordentligt åtdragna innan användning.

Användning

1. Förbered arbetsområdet genom att rensa bort alla föremål som kan orsaka olyckor.
2. Placera det material som ska sågas på en stabil yta.
3. Använd sågen genom att föra den fram och tillbaka med jämn hastighet.
4. Undvik att trycka för hårt på sågen; låt den göra jobbet.
5. Avsluta användningen genom att stänga av och rengöra sågen.

Avfallshantering

- När produkten inte längre är i bruk, se till att den kasseras på ett miljövänligt sätt.
- Kontrollera lokala riktlinjer för avfallshantering för att säkerställa korrekt kassering av metall och plast.

Kontaktinformation för vidare support

- För frågor om säkerhet och användning, vänligen kontakta tillverkaren eller återförsäljaren där produkten köptes.

Vi tackar för att du valt Hooyman Survival Ring Saw och önskar dig en säker och lyckad användning!