

SCOUT™ 3.5" Pointed Knife

The SCOUT™ 3.5" Pointed Knife is the ideal knife for the spear fisherman. This knife does it all—from braining a fish to cutting through rope. The Pointed Dive Knife comes fully-loaded with our iconic, non-slip grip handle and titanium-nitride coated blade. The full-tang construction is designed with a razor sharp edge and a serrated edge. Finally, our dive knives include a deluxe locking sheath—specifically designed for spearfishing that includes rubber straps for on the body hold.

NO IMAGE
AVAILABLE

Attributes

- Name: SCOUT™ 3.5" Pointed Knife
- Manufacturer: BUBBA
- Product no.: EU1001826
- Mfr. No.: 1107806
- Size: 3.5"
- Delivery weight: 2kg
- UPC: 661120079538

Table of Contents

- [Startpage](#)
- [English: BUBBA SCOUT™ 3.5" Pointed Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA SCOUT™ 3.5" spetsig kniv](#)

BUBBA SCOUT™ 3.5" Pointed Knife Safety Instructions

Introduction

Thank you for choosing the BUBBA SCOUT™ 3.5" Pointed Knife. This knife is designed for spear fishing and various cutting tasks. To ensure your safety and the longevity of your knife, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always use the knife as intended. This knife is designed for cutting and should not be used for prying or other unintended purposes.
- Keep the knife out of reach of children. This knife is not a toy and should only be handled by adults or under adult supervision.
- Inspect the knife regularly for any signs of damage or wear. If any issues are found, discontinue use and contact the manufacturer.
- Store the knife in a secure location, preferably in its sheath, when not in use.
- Be aware of your surroundings when using the knife to avoid accidental injury to yourself or others.

Specific Safety Precautions for Use

- Always cut away from your body and keep your fingers clear of the blade.
- Use the knife on a stable surface to prevent slipping.
- When using the serrated edge, ensure the material you are cutting is securely held in place.
- If the knife becomes stuck while cutting, do not force it. Carefully maneuver the knife to free it.
- Avoid using the knife in wet conditions unless necessary. If wet, ensure the handle provides a secure grip before use.

Instructions for Installation and Usage

• Using the Knife:

1. Remove the knife from its sheath.
2. Ensure your hands are dry before gripping the handle.
3. Hold the knife firmly by the handle, ensuring your fingers are away from the blade.
4. Use the knife for its intended purpose, following the specific safety precautions outlined above.

• Storing the Knife:

1. After use, clean the knife with fresh water and dry it thoroughly.
2. Place the knife back into its deluxe locking sheath.
3. Store the sheath in a dry place, away from children and pets.

• Maintenance:

1. Regularly check the blade for sharpness. If dull, sharpen according to the manufacturer's instructions.
2. Inspect the sheath and locking system for any signs of damage.
3. Clean the handle and blade to prevent corrosion, especially after exposure to saltwater.

Disposal Instructions

- Dispose of the knife responsibly. If the knife is damaged beyond repair, follow local regulations for disposal of sharp objects.
- Ensure the knife is wrapped or secured before disposal to prevent injury to waste handlers.

Contact Information for Further Support

For any inquiries regarding safety, maintenance, or product issues, please refer to the manufacturer's contact information provided with your product packaging or visit the official website.

By adhering to these safety instructions, you can ensure a safe and enjoyable experience with your BUBBA SCOUT™ 3.5" Pointed Knife. Always prioritize safety and responsible usage to maximize the benefits of this versatile tool.

Säkerhetsinstruktioner för BUBBA SCOUT™ 3.5" spetsig kniv

Introduktion

Tack för att du har valt BUBBA SCOUT™ 3.5" spetsig kniv. Denna kniv är designad för att vara säker och effektiv för spjutfiskare. Det är viktigt att du läser och följer dessa säkerhetsinstruktioner noggrant för att säkerställa en säker användning av produkten.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Förvara kniven utom räckhåll för barn och andra som inte är utbildade att använda den.
- Kontrollera knivens skick innan användning. Byt ut den om den är skadad eller sliten.
- Använd kniven endast för avsedda ändamål. Undvik att använda den för uppgifter som den inte är designad för.
- Var försiktig när du hanterar kniven för att undvika skador på dig själv eller andra.
- Rapportera eventuella skador eller olyckor som inträffar vid användning av kniven.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med ett fast grepp för att undvika att den glider ur handen.
- Skär alltid bort från kroppen för att minska risken för skador.
- Använd kniven på en stabil yta för att förhindra olyckor.
- Använd skyddshandskar om möjligt för att skydda händerna mot skärskador.
- Var försiktig med knivens spetsiga del när du hanterar den.
- Tänk på omgivningen och se till att ingen står i vägen för din rörelse när du använder kniven.

Instruktioner för installation och användning

1. **Kontrollera kniven:** Innan användning, inspektera kniven för eventuella skador. Kontrollera att bladet är skarpt och att handtaget är i gott skick.
2. **Förvaring:** Förvara kniven i det medföljande deluxe fodralet när den inte används. Se till att fodralet är stängt och säkert.
3. **Användning:**
 - Ta fram kniven ur fodralet med försiktighet.
 - Håll kniven i ett fast grepp och använd den på en säker yta.
 - Efter användning, rengör kniven och torka den noggrant för att förhindra rost.
4. **Återplacera i fodralet:** När du är klar med användningen, placera kniven tillbaka i fodralet och se till att det är stängt ordentligt.

Avfallsinstruktioner

- Kasta inte kniven i hushållsavfallet. Om kniven är skadad eller inte längre behövs, följ lokala riktlinjer för farligt avfall.
- Kontakta din lokala avfallshantering för råd om hur du ska göra dig av med kniven på ett säkert och miljövänligt sätt.

Kontaktinformation för ytterligare stöd

För frågor om säkerhet eller om du behöver mer information om produkten, vänligen kontakta en lokal återförsäljare eller besök tillverkarens webbplats för support.

Vi tackar för att du valt BUBBA SCOUT™ 3.5" spetsig kniv och önskar dig en säker och framgångsrik användning.